



R. A. KENT (ENGINEERS)

243 CARR LANE, TARLETON, PRESTON,
LANCASHIRE PR4 6YB.

Telephone: Hesketh Bank (0772) 814998
Fax: (0772) 815437

MORSE TUTOR

Speed range :5-40 W.P.M.

Delay range :0-4 seconds.

Battery requirements: 3 X 1.5V AA batteries.

To set the Morse Tutor in operation press any key other than [0].

[1] Selects letters in groups of five characters. When pressed the first two characters sent will be numbers which represent the current speed in W.P.M.

[2] Selects numbers in groups of five characters.

[3] Selects mixed numbers and letters in groups of five characters.

[4] Selects letters in random length groups of one to eight characters. When pressed the first two characters will be numbers, representing the delay in .1 of a second.

[5] Selects numbers in random length groups of one to eight characters.

[6] Selects mixed numbers and letters in random length groups of one to eight characters.

[7] and [9] Decreases and increases the overall speed.

[8] Selects the delay function, giving a time delay of up to four seconds between characters. To increase or decrease the delay, first press key eight followed by seven or nine.

[*] Selects high or low volume. NOTE: The low volume setting is adjustable via a small preset, which is located internally on the printed circuit board.

[] Resets the speed to twelve W.P.M. with no delay.

[0] OFF

If for any reason the morse tutor malfunctions and the reset key does not resume sending at twelve W.P.M., then disconnect and reconnect the battery. On reconnecting the battery the tutor should immediately start sending five letter groups at twelve W.P.M.